



Air Sniper Ultra Manual





Air Sniper Ultra Maintenance Manual

Thank you for purchasing an Air Sniper Ultra. This manual provides step-by-step instructions of how to set up and take care of your new unit.

Please contact AIR or your dealer to purchase replacement bulbs.

Videos of the instructions can be found on our website on the product page under maintenance videos or on our YouTube channel <https://www.airsniper.ca/>



Warnings

WARNING: Do not attempt to operate the UV-C lamps outside the unit. UV-C radiation is extremely harmful to unprotected (uncovered) eyes and skin.

Disconnect unit from power source before conducting maintenance

Bulbs contain small amounts of Mercury. Please dispose of responsibly according to your local regulations.

Bulbs may also be returned to AIR head office.



Warranty

Limited Warranty

Three Year Warranty Alpine Innovative Research Inc. (AIR) warrants the Air Sniper™ to be free from defects in the workmanship or materials under normal use and service (the “Warranty”) for a period of three (3) years (the “Warranty Period”) from the date of purchase through an AIR-authorized dealer/distributor. During the Warranty Period, should an Air Sniper™ be determined to be defective, AIR shall repair or replace the defective Air Sniper™ unit(s) (at AIR or dealer’s option) within a reasonable period.

Remedy Procedures

If the Air Sniper™ proves defective within the Warranty Period, the purchaser may choose one of the following remedies, after contacting AIR for a Return Authorization Number: 1. Return the defective Air Sniper™ unit to the dealer/distributor from whom it was purchased together with a copy of the bill of sale, or dated proof of purchase thereof and the Return Authorization Number; or 2. Ship the defective Air Sniper™ unit directly to Air Alpine Innovative Research Customer Warranty Department along with the Return Authorization Number.

Limitations

This Warranty is the only representation regarding the Air Sniper™, by Alpine Innovative Research Inc. of merchantability and fitness for use and shall extend to three (3) years from the date of purchase. The warranty excludes replaceable UVC bulbs. If it is determined by either Alpine Innovative Research Inc or an authorized dealer/distributor that the defect is the result of damage caused by the purchaser, the Warranty is null and void.

Contact Us

Any questions or concerns pertaining to this Warranty may be directed to AIR by Email, telephone, or facsimile: AIR, Alpine Innovative Research.

Customer Warranty Department 6565- 40th Street SE Calgary, Alberta, Canada T2C 2T2C 2J9 Toll-Free 1 (888) 338-9549



How to set up your unit

This can also be found on the Air Sniper Quick-start guide

1. Carefully remove your Air Sniper Ultra from the shipping carton and remove all exterior packaging.
2. If your unit requires wall-mounting, unwrap the wall mount bracket and securely fasten it to the wall with screws.
3. If using a bracket, carefully clip the back of the unit into the bracket.
4. Plug the unit into the power source.
5. Once the unit is connected to a power source the touchscreen will light up.
6. The unit will begin at maximum speed to cycle the air out of the unit.
7. If there is bulb damage from shipping, the bulb detector will display red.
8. Set the desired fan speed of the unit (this can be changed via the dashboard system or touchscreen anytime).
9. Listen to the unit for a typical fan sound and if there are any “abnormal” sounds in the unit. If there are any abnormal sounds please turn the unit off immediately and contact the dealer or AIR, Alpine Innovative Research as damages may have occurred during transport.
10. Check the screen to see if there are any warning lights (bulb life, filter status) if all indicators present **green** or **Blue** the unit is cleaning your air effectively.

NoteThe unit effectively removes pathogens at all fan speeds. However, higher fan speeds increase the airflow, therefore increasing the volume of air treated at a time. Increasing the fan speed also increases the noise of the unit.**



WARNING: Do not attempt to operate the UV-C lamps outside the unit. UV-C radiation is extremely harmful to unprotected (uncovered) eyes and skin.



Connecting the unit to Wi-Fi

Can also be found under Air Sniper Quick Start Guide

All Air Sniper Ultra's can be connected to the local Wi-Fi network to allow for remote monitoring and control of the unit.

Link to video: <https://www.youtube.com/watch?v=rX2rzQnqiCM>

How to use touchscreen video: <https://www.youtube.com/watch?v=rX2rzQnqiCM>

1. Ensure the unit is turned on.
2. Locate the Wi-Fi button on the touchscreen (between the moon and the settings button).
3. Press the Wi-Fi button to access the network screen.
4. Click on **Set up Wi-Fi**.
5. The unit will then give you an option to select a network.
6. Choose the network that you would like to connect the unit to.
7. Enter the password for the network (if applicable).
8. The Wi-Fi button will turn **blue** when connected and display the current strength of the unit.

